




Care/Cleaning Instructions:

- Ensure your toy is switched off and the charger is completely disconnected before cleaning.
- We suggest cleaning your toy with toy cleaner or warm water and soap before and after each use.
- Use caution when cleaning your toy. Moisture in the battery component can cause malfunction.
- Be sure to let your toy dry completely before storing.
- Be sure to keep your toy separate from products made with different materials.
- Store in a clean, cool and dry place. Do not expose to direct sunlight.



Charging Instructions:

- All Viben toys come with a factory charge. We suggest fully charging your toy before use. Remote control uses one AAA battery.
- Only use the charger provided to charge your battery. Using any other charging cable may cause malfunction.
- Only use a AAA battery in your remote. Using any other battery may cause malfunction.
- Do not charge your battery in or around water.
- Epiphany features a plug in charging cable; simply insert the charging cable securely into the charging port.
- Epiphany will blink while charging.
- Epiphany's light will remain steady when your toy is fully charged.
- To change the battery in the remote, slide the back cover downward and replace the battery as needed.
- Full charging time is 2 hours.
- Play time is approximately 1 hour.



How to experience an Epiphany:

- Allow your toy to fully charge before play.
- Press and hold the power button for 3 seconds to power Epiphany on. Indicator light will illuminate and vibrate once when the toy is in standby mode.
- Press the function button once on the remote to turn Epiphany on and off.
- Press the function button on the remote or the toy to cycle through the 10 functions.
- Press and hold the power button for 3 seconds to turn Epiphany off. Repeat this step to turn off the remote. All indicator lights will turn off when the toy is fully powered down.
- Do not use your toy on swollen, bruised or inflamed areas including skin lacerations.
- Discontinue use immediately if irritation or discomfort occurs.

