


How to get Hypnotic:

- Allow your toy to fully charge before play.
- Press and hold the bottom button for 3 seconds to turn on/off vibration functions. Indicator light will become illuminated when function is on.
- Press the bottom button to toggle through the 10 vibration functions.
- Press and hold the middle button for 3 seconds to turn on/off swinging clitoral functions. Indicator light will become illuminated when function is on.
- Press the middle button to toggle through the 10 swinging clitoral functions.
- Press and hold the top button for 3 seconds to turn on/off thrusting functions. Indicator light will become illuminated when function is on.
- Press the top button to toggle through the 7 thrusting functions.
- Hypnotic has a memory feature.
- All indicator lights will be off when your toy is fully powered off.
- Do not use your toy on swollen, bruised or inflamed areas including skin lacerations.
- Discontinue use immediately if irritation or discomfort occurs.

Care/Cleaning Instructions:

- Ensure your toy is switched off and the charger is completely disconnected before cleaning.
- We suggest cleaning your toy with toy cleaner or warm water and soap before and after each use.
- Use caution when cleaning your toy. Moisture in the battery component can cause malfunction.
- Be sure to let your toy dry completely before storing.
- Be sure to keep your toy separate from products made with different materials.
- Store in a clean, cool and dry place. Do not expose to direct sunlight. Keep
- Hypnotic away from magnets and other such polarized materials.
- Polarized materials such as magnets can cause malfunction.



Charging Instructions:

- All Viben toys come with a factory charge. We suggest fully charging your toy before use.
- Only use the charging cable provided to charge your battery. Using any other charging cable may cause malfunction.
- Do not charge your battery in or around water.
- Hypnotic features a magnetic charging cable; simply attached the cable to the two magnetic connectors at the bottom of the toy.
- Hypnotic will blink while charging.
- Hypnotic's light will remain steady when your toy is fully charged.
- Full charging time is 90 minutes.
- Play time is approximately 30 minutes.