





Care/Cleaning Instructions:

- Ensure your toy is switched off and the charger is completely disconnected before cleaning.
- We suggest cleaning your toy with toy cleaner or warm water and soap before and after each use.
- Use caution when cleaning your toy. Moisture in the battery component can cause malfunction.
- Be sure to let your toy dry completely before storing.
- Be sure to keep your toy separate from products made with different materials.
- Store in a clean, cool and dry place. Do not expose to direct sunlight.



Charging Instructions:

- All Viben toys come with a factory charge. We suggest fully charging your toy before use.
- Only use the charging cable provided to charge your battery. Using any other charging cable may cause malfunction.
- Do not charge your battery in or around water.
- Pzazz features a magnetic charging cable; simply connect the charging cable securely to the two magnetic connectors on the back of the toy.
- Pzazz's indicator lights will blink while charging.
- When your toy is fully charged, the indicator lights will remain illuminated.
- Full charging time is 90 minutes.
- Play time is approximately 2 hours.



How to feel Pzazz:

- Allow your toy to fully charge before play.
- Press and hold the middle function button for 3 seconds to power on/off, Pzazz will go into Standby Mode and light will remain luminated while the device is powered on. Indicator light will turn off when the device is powered fully off.
- Press the bottom button to toggle through different vibration patterns.
- Press the middle button to toggle through the different thumping functions. Hold for 3 seconds to power off.
- Press the top Power Boost Button to turn on/off the Power Boost Function.
- All indicator lights will be off when Pzazz is fully powered off.
- Do not use your toy on swollen, bruised or inflamed areas including skin lacerations.
- Discontinue use immediately if irritation or discomfort occurs.